Customizable features

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

Item	Function	Default setting	Customized setting
Smart access system with push-button start (→P. 28)	Operation signal (Emergency flashers)	On	Off
	Operation signal (Buzzer)	On	Off
Wireless remote control (→P. 40)	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Automatic door lock function to be activated if door is not opened after being unlocked	On	Off

<table>
<tr><th>Item</th><th>Function</th><th>Default setting</th><th>Customized setting</th></tr>
<tr><td rowspan="9">Wireless remote control (→P. 40)</td><td rowspan="2">Time elapsed before automatic door lock function is activated if door is not opened after being unlocked</td><td rowspan="2">60 seconds</td><td>30 seconds</td></tr>
<tr><td>120 seconds</td></tr>
<tr><td>Operation signal (Emergency flashers)</td><td>On</td><td>Off</td></tr>
<tr><td>Operation signal (Buzzer)</td><td>On</td><td>Off</td></tr>
<tr><td>Door lock buzzer</td><td>On</td><td>Off</td></tr>
<tr><td>Trunk unlocking function</td><td>On</td><td>Off</td></tr>
<tr><td rowspan="2">Trunk unlocking operation</td><td rowspan="2">Push and hold</td><td>Push twice</td></tr>
<tr><td>One short push</td></tr>
<tr><td>Panic function</td><td>On</td><td>Off</td></tr>
</table>

Item	Function	Default setting	Customized setting
Door lock (→P. 43)	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Speed-detecting automatic door lock function (Manual transmissions)	On	Off
	Speed-detecting automatic door lock function (Automatic transmissions)	Off	On
	Opening driver's door unlocks all doors (Manual transmissions)	On	Off
	Opening driver's door unlocks all doors (Automatic transmissions)	Off	On
	Shifting gears to P unlocks all doors	On	Off
	Shifting gears to a position other than P locks all doors	On	Off
Steering wheel (→P. 68)	Auto tilt-away function	On	Off

Item	Function	Default setting	Customized setting
Power windows (→P. 75)	Linked door key operation	Open and close	Off
			Open only
			Close only
	Wireless remote control linked operation	Off	Open only
Moon roof (→P. 78)	Linked door key operation	Open and close	Off
			Open only
			Close only
	Linked operation of components when door key is used	Slide only	Tilt only
	Wireless remote control linked operation	Off	Open only
	Linked operation of components when wireless remote control is used	Slide only	Tilt only
Automatic light control system (→P. 165)	Light sensor sensitivity	Level 3	Level 1 to 5
	Time elapsed before headlights automatically turn off after doors are closed	30 seconds	0 seconds
			60 seconds
			90 seconds
Lights (→P. 166)	Daytime running light system (U.S.A. only)	On	Off

Item	Function	Default setting	Customized setting
Windshield wipers and washer (→P. 169)	Switching operation when the vehicle is stationary	On	Off
	Drip prevention function	On	Off
	Time elapsed before the drip prevention function operates	Variable depending on the vehicle speed	3 seconds
Intuitive parking assist (→P. 179)	Back sensor operation display and buzzer	On	Off
	Buzzer volume	Level 3	Level 1 to 5
	Distance which a sensor detects	4.9 ft. (150 cm)	2.0 ft. (60 cm)
Illumination (→P. 315)	Time elapsed before lights turn off	15 seconds	7.5 seconds
			30 seconds
	Operation when the doors are unlocked	On	Off
	Operation after the “ENGINE START STOP” switch is turned OFF	On	Off
	Front footwell lights	On	Off
	Shift lever light	On	Off
	Outer foot light	On	Off
Seat belt reminder (→P. 463)	Vehicle speed linked seat belt reminder buzzer	On	Off

Multi-information display (→P. 160)

Country	Available languages
Canada	English and French